


FIG. 10

F56. 10


Detect Menu Request 1210 Display selected Menu ~220 MAKE MENU BAR OF Achive Menu selectable IN ~230 Desponse to NAVIGATION
FRONT that Indicates the MONU BAR. Petect Selection Front FOR Selecting The Menu ~240 BAR of the Active Menu When the MENU BAR, Is MADE selectable Cancel Active Menu IN Response to Selection INPUT

FI6. 2



£26.3





F=6.4